

KITLG (Human) ELISA Kit

Catalog Number KA1022

96 assays

Version: 04

Intended for research use only

www.abnova.com



Table of Contents

Introduction3
Background3
Principle of the Assay3
General Information4
Materials Supplied4
Storage Condition4
Materials Required but Not Supplied4
Precautions for Use5
Assay Protocol6
Reagent Preparation6
Sample Preparation6
Assay Procedure7
Data Analysis9
Calculation of Results9
Performance Characteristics10
Resources11
Troubleshooting
References
Plate Layout



Introduction

Background

Stem Cell Factor (SCF) is also known as c-Kit receptor ligand, KL, steel factor, or mast cell growth factor. It is expressed in fibroblasts, thymus tissue, spleen, testes, placenta and mast cells. SCF is a cytokine that exists in two forms produced by alternative splicing: a soluble form of approximately 31 kDa and a membrane-bound form of approximately 32 kDa, lacking the proteolytic site for processing into the soluble form (1-4). SCF plays an important role in hematopoiesis, reproduction, and melanogenesis. It is also involved in proliferation and differentiation of mast cells. It stimulates mast cell activation in human bronchi and induces smooth muscle cell contraction (5).

Principle of the Assay

The KITLG (Human) ELISA Kit is designed for detection of SCF in human plasma, serum and cell culture samples. This assay employs a quantitative sandwich enzyme immunoassay technique that measures human SCF in approximately 4 hours. A polyclonal antibody specific for human SCF has been pre-coated onto a 96-well microplate with removable strips. SCF in standards and samples is sandwiched by the immobilized antibody and a biotinylated polyclonal antibody specific for human SCF, which is recognized by a streptavidin-peroxidase (SP) conjugate. All unbound material is washed away and a peroxidase enzyme substrate is added. The color development is stopped and the intensity of the color is measured.



General Information

Materials Supplied

List of component

Component	Amount	
Human SCF Microplate: A 96-well polystyrene microplate (12 strips of 8 wells) coated	00 (0.40)	
with a polyclonal antibody against human SCF.	96 (8x12) wells	
Sealing Tapes: Each kit contains pre-cut, pressure-sensitive sealing tapes that can be	3 slices	
cut to fit the format of the individual assay.	5 SIICES	
Human SCF Standard: Human SCF in a buffered protein base (lyophilized).	128 ng	
Biotinylated Human SCF Antibody (100x): A 100-fold concentrated biotinylated	<u> </u>	
polyclonal antibody against human SCF.	60 µL	
EIA Diluent Concentrate (10x): A 10-fold concentrated buffered protein base.	20 mL	
Wash Buffer Concentrate (20x): A 20-fold concentrated buffered surfactant.	30 mL x 2	
SP Conjugate (100x): A 100-fold concentrate.	80 µL	
Chromogen Substrate (1x): A stabilized peroxidase chromogen substrate		
tetramethylbenzidine.	7 mL	
Stop Solution (1x): A 0.5 N hydrochloric acid solution to stop the chromogen substrate	11 ml	
reaction .	11 mL	

Storage Condition

- ✓ Upon arrival, immediately store components of the kit at recommended temperatures up to the expiration date.
- ✓ Store SP Conjugate and Biotinylated Antibody at -20°C.
- ✓ Store Microplate, Diluent Concentrate (10x), Wash Buffer, Stop Solution, and Chromogen Substrate at 2-8°C.
- ✓ Unused microplate wells may be returned to the foil pouch with the desiccant packs and resealed. May be stored for up to 30 days in a vacuum desiccator.
- ✓ Store standard at 2-8°C before reconstituting with Diluent and at -20°C after reconstituting with Diluent.

Materials Required but Not Supplied

- ✓ Microplate reader capable of measuring absorbance at 450 nm
- ✓ Pipettes (1-20 μL, 20-200 μL, 200-1000 μL and multiple channel)
- ✓ Deionized or distilled reagent grade water



Precautions for Use

- ✓ This product is for Research Use Only and is not intended for use in diagnostic procedures.
- ✓ Prepare all reagents (diluent buffer, wash buffer, standard, biotinylated antibody, and SP conjugate) as instructed, prior to running the assay.
- ✓ Prepare all samples prior to running the assay. The dilution factors for the samples are suggested in this insert. However, the user should determine the optimal dilution factor.
- ✓ Spin down the SP conjugate vial and the biotinylated-antibody vial before opening and using contents.
- \checkmark The kit should not be used beyond the expiration date.
- ✓ The Stop Solution is an acid solution.



Assay Protocol

Reagent Preparation

- ✓ Freshly dilute all reagents and bring all reagents to room temperature before use.
- EIA Diluent Concentrate (10x): Dilute the EIA Diluent Concentrate 10-fold with reagent grade water to produce a 1x solution. When diluting the concentrate, make sure to rinse the bottle thoroughly to extract any precipitates left in the bottle. Mix the 1x solution gently until the crystals have completely dissolved. Store for up to 30 days at 2-8°C.
- Human SCF Standard: Reconstitute the Human SCF Standard (128 ng) with 3.2 mL of EIA Diluent to generate a 40 ng/mL standard stock solution. Allow the vial to sit for 10 minutes with gentle agitation prior to making dilutions. Prepare duplicate or triplicate standard points by serially diluting from the standard stock solution (40 ng/mL) 4-fold with EIA Diluent to produce 10, 2.5, 0.625, and 0.156 ng/mL solutions. EIA Diluent serves as the zero standard (0 ng/mL). Any remaining stock solution should be stored at -20°C and used within 30 days. Avoid repeated freeze-thaw cycles.

Standard Point	Dilution	[SCF] (ng/mL)
P1	1 part Standard (40 ng/mL)	40.00
P2	1 part P1 + 3 parts EIA Diluent	10.00
P3	1 part P2 + 3 parts EIA Diluent	2.500
P4	1 part P3 + 3 parts EIA Diluent	0.625
P5	P5 1 part P4 + 3 parts EIA Diluent	
P6	EIA Diluent	0.000

✓ Biotinylated Human SCF Antibody (100x): Spin down the antibody briefly and dilute the desired amount of the antibody 100-fold with EIA Diluent to produce a 1x solution. The undiluted antibody should be stored at -20°C.

- ✓ Wash Buffer Concentrate (20x): Dilute the Wash Buffer Concentrate 20-fold with reagent grade water to produce a 1x solution. When diluting the concentrate, make sure to rinse the bottle thoroughly to extract any precipitates left in the bottle. Mix the 1x solution gently until the crystals have completely dissolved.
- ✓ SP Conjugate (100x): Spin down the SP Conjugate briefly and dilute the desired amount of the conjugate 100-fold with EIA Diluent to produce a 1x solution. The undiluted conjugate should be stored at -20°C.

Sample Preparation

Plasma: Collect plasma using one-tenth volume of 0.1 M sodium citrate as an anticoagulant. Centrifuge samples at 3000 x g for 10 minutes and collect plasma. A 2-fold sample dilution is suggested into EIA Diluent; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles (EDTA or Heparin can also be used as anticoagulant).



- ✓ Serum: Samples should be collected into a serum separator tube. After clot formation, centrifuge samples at 3000 x g for 10 minutes and remove serum. A 2-fold sample dilution is suggested into EIA Diluent; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.
- Cell Culture Supernatants: Centrifuge cell culture media at 1500 rpm for 10 minutes at 4°C to remove debris and collect supernatant. Samples can be stored at -80°C. Avoid repeated freeze-thaw cycles.
 Applicable samples may also include biofluids, cell culture, and tissue homogenates. If necessary, user should determine optimal dilution factor depending on application needs.

Guidelines for Dilutions of 100-fold or Greater					
(for reference only; please follow the	insert for specific dilution suggested)				
100x 10000x					
A) 4 μL sample : 396 μL buffer (100x)	A) 4 μL sample : 396 μL buffer (100x)				
= 100 fold dilution	B) 4 μL of A : 396 μL buffer (100x)				
	= 10000 fold dilution				
Assuming the needed volume is less than or equal to	Assuming the needed volume is less than or equal to				
400 µL.	400 μL.				
1000x	100000x				
A) 4 μL sample : 396 μL buffer (100x)	A) 4 μL sample: 396 μL buffer (100x)				
B) 24 μ L of A : 216 μ L buffer (10x) = 1000 fold dilution	B) 4 μL of A : 396 buffer (100x)				
	C) 24 µL of B : 216 µL buffer (10x)				
	= 100000 fold dilution				
Assuming the needed volume is less than or equal to	Assuming the needed volume is less than or equal to				
240 μL.	240 μL.				

✓ Refer to Dilution Guidelines for further instruction.

Assay Procedure

- 1. Prepare all reagents, standard solutions, and samples as instructed. Bring all reagents to room temperature before use. The assay is performed at room temperature (20-25°C).
- 2. Remove excess microplate strips from the plate frame and return them immediately to the foil pouch with desiccant inside. Reseal the pouch securely to minimize exposure to water vapor and store in a vacuum desiccator.
- Add 50 µL of Human SCF Standard or sample to each well. Gently tap plate thoroughly coated the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 2 hours. Start the timer after the last addition.
- 4. Wash the microplate manually or automatically using a microplate washer. Invert the plate and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If washing manually,



wash five times with 200 μ L of Wash Buffer per well. Invert the plate each time and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If using a microplate washer, wash six times with 300 μ L of Wash Buffer per well; invert the plate and hit 4-5 times on absorbent material to completely remove the liquid.

- Add 50 µL of Biotinylated Human SCF Antibody to each well. Gently tap plate thoroughly coated the wells.
 Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 1 hour.
- 6. Wash the microplate as described above.
- Add 50 µL of SP Conjugate to each well. Gently tap plate thoroughly coated the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 30 minutes. Turn on the microplate reader and set up the program in advance.
- 8. Wash the microplate as described above.
- Add 50 µL of Chromogen Substrate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Incubate in ambient light for 8 minutes or until the optimal blue color density develops.
- 10. Add 50 μL of Stop Solution to each well. The color will change from blue to yellow. Gently tap plate to ensure thorough mixing. Break any bubbles that may have formed.
- 11. Read the absorbance on a microplate reader at a wavelength of 450 nm immediately. If wavelength correction is available, substrate readings at 570 nm from those at 450 nm to correct optical imperfections. Otherwise, read the plate at 450 nm only. Please note that some unstable black particles may be generated at high concentration points after stopping the reaction for about 10 minutes, which will reduce the readings.
- ✓ Assay Summary
- 1. Add 50 µL of Standard or Sample per well. Incubate 2 hours.
- 2. Wash, then and 50 µL of Biotinylated Antibody per well. Incubate 1 hour.
- 3. Wash, then add 50 µL of SP Conjugate per well. Incubate 30 minutes.
- 4. Wash, then add 50 µL of Chromogen Substrate per well. Incubate 8 minutes.
- 5. Add 50 µL of Stop Solution per well. Read at 450 nm immediately.



Data Analysis

Calculation of Results


- ✓ Calculate the mean value of the duplicate or triplicate readings for each standard and sample.
- ✓ To generate a Standard Curve, plot the graph using the standard concentrations on the x-axis and the corresponding mean 450 nm absorbance (OD) on the y-axis. The best-fit line can be determined by regression analysis using log-log or four-parameter logistic curve-fit.
- ✓ Determine the unknown sample concentration from the Standard Curve and multiply the value by the dilution factor.
- ✓ Typical Data

The typical data is provided for reference only. Individual laboratory means may vary from the values listed. Variations between laboratories may be caused by technique differences.

Standard Point	ng/mL	OD	Average OD				
P1	40.0	2.289	2.287				
ГІ	40.0	2.285	2.201				
P2	10.0	1.972	1.935				
F2	10.0	1.897	1.955				
P3	2.50	1.109	1.107				
гэ	2.50	1.104	1.107				
P4	0.625	0.453	0.444				
Г4		0.434	0.444				
P5	0.156	0.213	0.211				
F0	0.150	0.208	0.211				
P6	0.000	0.096	0.094				
FO	0.000	0.092	0.094				
Sample	e: Pooled Normal	0.471	0.469				
Sodium	Citrate Plasma (2x)	0.467	0.409				

✓ Standard curve

The curve is provided for illustration only. A standard curve should be generated each time the assay is performed.





- ✓ Reference Value
- Normal SCF plasma level range from 0.5-1.8 ng/mL.
- Plasma samples from healthy adults were tested (n=40). On average, human SCF level was 1.0 ng/mL.

Performance Characteristics

- ✓ The minimum detectable dose of human SCF as calculated by 2SD from the mean of a zero standard was established to be 0.09 ng/mL.
- ✓ Intra-assay precision was determined by testing three plasma samples twenty times in one assay.
- ✓ Inter-assay precision was determined by testing three plasma samples in twenty assays.

	Intra	a-Assay Preci	sion	Inter-Assay Precision			
Sample	1	2	3	1	2	3	
n	20	20	20	20	20	20	
CV (%)	5.3% 5.3% 4.1%		6 10.1% 9.7% 10.3%				
Average CV (%)	4.9%			10.0%			

✓ Recovery

Standard Added Value	0.625-10 ng/mL
Recovery %	87-108%
Average Recovery %	95%

✓ Linearity

Plasma and serum samples were serially diluted to test for linearity.

Average Percentage of Expected Value (%)						
Sample Dilution Plasma Serum						
1x	96%	98%				
2x	101%	99%				
4x	104%	105%				

✓ Cross-Reactivity

Species	% Cross Reactivity
Canine	None
Bovine	None
Monkey	< 10%
Mouse	None
Rat	None
Swine	None



Resources

Troubleshooting

Issue	Causes	Course of Action
		Check the expiration date listed before use.
	Use of improper components	• Do not interchange components from different lots.
		Check that the correct wash buffer is being used.
		Check that all wells are empty after aspiration.
		Check that the microplate washer is dispensing
	Improper wash step	properly.
		• If washing by pipette, check for proper pipetting
		technique.
ion	Splashing of reagents while loading	• Pipette properly in a controlled and careful manner.
Low Precision	wells	
v Pr		• Pipette properly in a controlled and careful manner.
Lo	Inconsistent volumes loaded into wells	Check pipette calibration.
		Check pipette for proper performance.
	Insufficient mixing of reagent dilutions	Thoroughly agitate the lyophilized components after
		reconstitution.
		Thoroughly mix dilutions.
	Improperly sealed microplate	Check the microplate pouch for proper sealing.
		• Check that the microplate pouch has no punctures.
		Check that three desiccants are inside the
		microplate pouch prior to sealing.
	Microplate was left unattended between	• Each step of the procedure should be performed
	steps	uninterrupted.
ensity	Omission of step	Consult the provided procedure for complete list of
Inte		steps.
gnal	Step performed in incorrect order	Consult the provided procedure for the correct
h Si		order.
Hig	Insufficient amount of reagents added to	Check pipette calibration.
w or	wells	Check pipette for proper performance.
V Lo	Wash step was skipped	• Consult the provided procedure for all wash steps.
Unexpectedly Low or High Signal Int	Improper wash buffer	• Check that the correct wash buffer is being used.
<pre></pre>		Consult reagent preparation section for the correct
Jney	Improper reagent preparation	dilutions of all reagents.
	Insufficient or prolonged incubation	Consult the provided procedure for correct
	periods	incubation time.



		•	Sandwich ELISA: If samples generate OD values higher
			than the highest standard point (P1), dilute samples
			further and repeat the assay.
	Non optimal comple dilution	•	Competitive ELISA: If samples generate OD values lower
	Non-optimal sample dilution		than the highest standard point (P1), dilute samples
ĿĬ			further and repeat the assay.
		•	User should determine the optimal dilution factor for
Cur			samples.
Deficient Standard Curve	Contomination of recordents		A new tip must be used for each addition of different
Stan	Contamination of reagents		samples or reagents during the assay procedure.
ent S	Contents of wells evaporate		Verify that the sealing film is firmly in place before placing
eficie			the assay in the incubator or at room temperature.
ă		•	Pipette properly in a controlled and careful manner.
	Improper pipetting	•	Check pipette calibration.
		•	Check pipette for proper performance.
	Insufficient mixing of reagent	•	Thoroughly agitate the lyophilized components after
	dilutions		reconstitution.
	ulutions		Thoroughly mix dilutions.

References

- 1. Flanagan JG and Leder P (1990) Cell 63:185-194
- 2. Williams DE et al. (1990) Cell 63:167-174
- 3. Brannan CI et al. (1991) Proc. Natl. Acad. Sci. U.S.A. 88: 4671–4674
- 4. Zsebo KM et al. (1990) Cell 63:213-224
- 5. Undem BJ et al. (1994) Am. J. Respir. Cell Mol. Biol. 11:646-650



Plate Layout

						r	r	
12								
11								
10								
6								
8								
7								
9								
ນ								
4								
e								
2								
۲								
	A	В	С	D	Ш	Ш	Ċ	Т